

05

DAF

Group	Page
Spring Suspension	001
Cabin	009
Stabilizer	017
Brake	026
Axle & Wheel	040
Steering & Suspension	041
Engine	056
Shaft	057
Gearbox	058
Radiator & Fan Group	058
Shock Absorber & Gas Spring	061
Air Suspension	063
Air Filter	063



Auger Nr.	OEM Nr.	Description	Model	Picture	
53964	1357 764	Rubber Bushing for Spring ø24xø63x86	65 CF 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85 CF 85 IV	LF 55 XF 105 XF 95 YTZ 95	
55203	1368 283	Rubber Bushing for Spring 24xø63x106	65 CF 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85 CF 85 IV	XF 105 XF 95	
55210	1671 219	Rubber Bushing for Spring ø24xø61x86	CF 75 CF 75 IV CF 85 CF 85 IV XF 105 XF 95		
55209	1611 229	Rubber Bushing for Spring ø24xø60x83	85 CF 95 XF CF 85 XF 95		
53380	1401 465	Rubber Bushing for Spring ø22xø51.5x76	LF 45		
53384	1401 131	Rubber Bushing for Spring ø32xø86x133	LF 55		

Auger Nr.	OEM Nr.	Description	Model	Picture	
55199	1681 114	Silent Block ø59.5x18/22/128	CF 85 CF 85 IV XF 105 XF 95		
55200	0654 792	Silent Block ø50x144	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV	F 28 - F 36 / N 28 TT 2100 F 75 F 85 F 95 XF 105 XF 95	
51862	0377 630	Plastic Bushing for Spring ø32.8xø69x98	BUS		
51926	0361 477	Spring Buffer ø74.5x17	BUS 65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 85 CF 85 IV F 28 - F 36	N 28 TT 2100 F 5 - F 27 F 65 F 75 F 85 F 95 XF 105 XF 95	
53375	0266 031	Spring Buffer ø65.5x67	65 CF 75 CF 85 CF 95 XF 95 XF 530 F 28 - F 36 N 28	TT 2100 F 5 - F 27 F 65 F 75 F 85 F 95 XF 95	
55192	1779 767 1699 564	Spring Cushion 205	CF 75 CF 75 IV CF 85 CF 85 IV XF 105 XF 95		
55191	0073 259	Spring Bracket ø98/ø95/ø78	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85	CF 85 IV F 28 - F 36 N 28 TT 2100 F 75/85/95 XF 105 XF 95	









Auger Nr.	O.E.M. Nr.	A	B	C	Type	Repair Kit
51913	0299 039	ø32	158	-	1	51906
51909	0389 071	ø26	136	-	1	53425
55193	1205 666	ø32	140	-	1	-
55194	0096 108	ø26	205	-	1	-
55196	1345 538	ø26	202	-	1	-
51914	0643 499	ø35	160	-	2	-
51916	0089 781	ø30	139	-	2	-
51917	0645 232	ø25	136	-	2	-
51918	0645 231	ø25	136	-	2	-
53992	0645 233	ø35	160	-	2	-
53993	0645 234 - 0501 576	ø35	160	-	2	-
55195	0655 129	ø42	148	-	2	-
51915	0763 009	ø30	152	-	3	-
53421	0299 812	ø25	64.5	-	4	-



Auger Nr.	O.E.M. Nr.	A	B	C	Type	Repair Kit
51897	0679 253	ø26	ø31	52.5	1	53425
51899	0659 666 0643 384 - 0631 075	ø35	ø42	97.5	1	-
51901	0649 531	ø45	ø52	97.5	1	-
51902	0661 283	ø47	ø52	97.5	1	-
51903	0654 870	ø35	ø42	77.5	1	-
51904	0645 245	ø25	ø32.1	77.5	1	-
51905	0266 412	ø32	ø37	72.5	1	51906
55204	0660 684	ø45	ø50	68.5	1	-
55206	0092 961	ø32	ø37	52.5	1	-
55207	0653 262	ø72	ø78	55	1	-
51898	0679 254	ø31	ø39	75.5	2	53425
55205	0092 960	ø37	ø49	75.5	2	-
51900	0266 411	ø37	ø49	95.5	2	51906

Auger Nr.	OEM Nr.	Description	Model	Picture	
51913	0299 039	Spring Pin ø32x158	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 85	CF 85 IV F 5 - F 27 F 65 F 75 F 85 F 95 XF 95	
51914	0643 499	Spring Pin ø35x160	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27		
51915	0763 009	Spring Pin M20x2.5/ø30x152	F 5 - F 27		
51916	0089 781	Spring Pin ø30x139	F 5 - F 27		
51917	0645 232	Spring Pin ø25x136	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27		
51918	0645 231	Spring Pin ø25x136	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 95		
51909	0389 071	Spring Pin ø26x136	65 CF 75 CF 85 CF 95 XF 95 XF 530 F 28 - F 36 N 28	TT 2100 F 5 - F 27 F 65 F 75 F 85 F 95 XF 95	

Auger Nr.	OEM Nr.	Description	Model	Picture	
53421	0299 812	Spring Pin ø25x64.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 5 - F 27 F 65 F 75 F 85 F 95 XF 105 XF 95	
53992	0645 233	Spring Pin ø35x160	F 28 - F 36 N 28 TT 2100		
53993	0645 234 0501 576	Spring Pin ø35x160	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27		
55193	1205 666	Spring Pin ø32x140	75 CF 85 CF 95 XF CF 75 CF 75 IV CF 85 CF 85 IV	F75 F 85 F 95 XF 105 XF 95	
55194	0096 108	Spring Pin ø26x205	75 CF 85 CF 95 XF F 85 F 95		
55195	0655 129	Spring Pin ø42x148	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV	F 28 F 36 / N 28 TT 2100 F 75 F 85 F 95 XF 105 XF 95	
55196	1345 538	Spring Pin ø26x202	75 CF 85 CF 95 XF F 85		

Auger Nr.	OEM Nr.	Description	Model	Picture	
51897	0679 253	Spring Bushing	65 CF	TT 2100	
		ø26xø31x52.5	75 CF	F 5 - F 27	
			85 CF	F 65	
			95 XF	F 75	
			95 XF 530	F 85	
			F 28 - F 36	F 95	
			N 28	XF 95	
51898	0679 254	Spring Bushing	65 CF	TT 2100	
		ø31xø39x75.5	75 CF	F 5 - F 27	
			85 CF	F 65	
			95 XF	F 75	
			95 XF 530	F 85	
			F 28 - F 36	F 95	
			N 28	XF 95	
51899	0659 666 0643 384 0631 075	Spring Bushing	BUS		
		ø35xø42x97.5	F 28 - F 36		
			N 28		
			TT 2200		
			F 5 - F 27		
51900	0266 411	Spring Bushing	65 CF	CF 85 IV	
		ø37xø49x95.5	75 CF	F 5 - F 27	
			85 CF	F 65	
			95 XF	F 75	
			95 XF 530	F 85	
			CF 75	F 95	
			CF 85	XF 95	
51901	0649 531	Spring Bushing	F 28 - F 36		
		ø45xø52x97.5	N 28		
			TT 2100		
			F 5 - F 27		
51902	0661 283	Spring Bushing	BUS		
		ø47xø52x97.5	F 5 - F 27		
51903	0654 870	Spring Bushing	F 5 - F 27		
		ø35xø42x77.5	F 95		

Auger Nr.	OEM Nr.	Description	Model	Picture	
51904	0645 245	Spring Bushing ø25xø32x77.5	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 95		
51905	0266 412	Spring Bushing ø32xø37x72.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 85 CF 85 IV	F 5 - F 27 F 65 F 75 F 85 F 95 XF 95	
55204	0660 684	Spring Bushing ø45xø50x68.5	65 CF 75 CF 85 CF 95 XF F 28 F 36 N 28 TT 2100	F 65 F75 F 85 F 95	
55205	0092 960	Spring Bushing ø37xø49x75.5	75 CF 85 CF 95 XF CF 75 CF 75 IV CF 85 CF 85 IV F 75	F 85 F 95 XF 105 XF 95	
55206	0092 961	Spring Bushing ø32xø37x52.5	75 CF 85 CF 95 XF CF 75 CF 75 IV CF 85 CF 85 IV F 75	F 85 F 95 XF 105 XF 95	
55207	0653 262	Spring Bushing ø72xø78x55	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV F 28	F 36 N 28 TT 2100 F 75 F 85 F 95 XF 105 XF 95	



Auger Nr.	O.E.M. Nr.	A	B	C	Type	Repair Kit
54875	1236 238	ø24,5	ø35	11	1	53425
54856	1261 846	ø30,5	ø45	11	1	51906
55249	1401 142	M22x2.5	220	SW32	2	55213
55250	1365 622	M24x3	140	SW36	2	55214

Auger Nr.	OEM Nr.	Description	Model	Picture
55213	1401 131 S	Rep. Kit Spring Bolt Assembly ø32xø86x133	LF 55	
55214	1357 764 S	Rep. Kit Spring Bolt Assembly ø24xø63x86	65 CF 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85 CF 85 IV	LF 55 XF 105 XF 95
51906	0299 039 S1	Spring Pin Set ø32x158	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 85 CF 85 IV F 65 F 75	F 85 F 95 XF 95
53425	0389 071 S1	Spring Pin Set ø26x136	65 CF 75 CF 85 CF 95 XF 95 XF 530 F 65 F 75 F 85 F 95 XF 95	51909 51898 51897 54875 51926

Auger Nr.	OEM Nr.	Description	Model	Picture
53386	1371 070	Cabin Bushing ø31xø73.5x26.5	65 CF 6-8-11 Ltr Engines 75 CF 85 CF CF 65 CF 65 II CF 65 IV CF 75	CF 75 IV CF 85 CF 85 IV 
51881	1290 794	Cabin Mounting ø20xø60x48	F 95	
51884	1314 545	Cabin Mounting ø20xø90x70	95 XF 95 XF 530 F 95 XF 95 XF 105	
51882	1290 795	Cabin Mounting ø51xø85x8	F 95	
51883	1396 202	Cabin Mounting ø20xø60/ø85x24	65 CF 75 CF 85 CF F 65 F 75 F 85	
51885	1254 641	Cabin Mounting ø20xø60/85x26.5	75 CF 85 CF F 65 F 75 F 85 F 95	







Auger Nr.	OEM Nr.	Description	Model	Picture
53382	1405 437	Cabin Mounting ø29xø70x117	LF 45 LF 55	
53385	1366 868	Cabin Mounting ø20xø74.5x62	65 CF 75 CF 85 CF CF 95 CF 75 CF 85 CF 85 IV	
53389	1405 552	Cabin Mounting ø14xø40x80.5	LF 45 LF 55	
53390	1403 089	Cabin Mounting ø11xø41.5x38	LF 45 LF 55	
53396	ACHF846	Cabin Mounting ø25.5xø85x32	F 55 F 45	
55189	1694 967	Cabin Mounting ø30xø55x25.3	XF 105 XF 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
55197	0365 453	Cabin Mounting ø12xø34x56	65 CF 75 CF 85 CF F28 F 36 N 28 TT 2100 F 65 F 75	F 85 F 95 LF 45 LF 55 
53422	1399 159	Seal for Cabin ø48xø70x5	XF 105 XF 95 YTZ 95	
53409	1656 266	Cabin Bushing ø25xø30/ø48x20	XF 105 XF 95 YTZ 95	
51910	0750 928	Bolt for Cabin ø25x130	65 CF 75 CF 85 CF F 65 F 75 F 85	
51886	1328 885	Cabin Bushing ø20/ø35x29/SW36	65 CF 75 CF 85 CF F 65 F 75 F 85	



Auger Nr.	O.E.M. Nr.	A	B	C	Type	Repair Kit
53072	1271 753 - 1271 385	$\varnothing 48.5$	$\varnothing 62$	5.7	1	51887-51888-51889 51891-51892-51894-51895
53422	1399 159	$\varnothing 47.7$	$\varnothing 70$	5	1	53450-53451
53044	1266 426	$\varnothing 25$	$\varnothing 30$	20.3	2	51887-51888-51889 51891-51892-51894-51895
53409	1656 266	$\varnothing 25$	$\varnothing 30$	20.3	2	53450-53451
53073	1332 194 - 0077 390	$\varnothing 25$	136.5	-	3	51887-51891-51892 51894-51895-53450-53451
51910	0750 928	$\varnothing 25$	130	-	3	51888-51889

Auger Nr.	OEM Nr.	Description	Model	Picture
51887	-	Rep. Kit for Cabin $\varnothing 20 \times \varnothing 60 \times 48$	F 95	
51888	-	Rep. Kit for Cabin $\varnothing 20 \times \varnothing 60 / \varnothing 85 \times 24$	65 CF 75 CF 85 CF F 65 F 75 F 85	
51889	-	Rep. Kit for Cabin $\varnothing 25$	65 CF 75 CF 85 CF F 65 F 75 F 85	
51890	-	Rep. Kit for Cabin $\varnothing 20 \times \varnothing 60 / \varnothing 85 \times 24$	65 CF 75 CF 85 CF F 65 F 75 F 85	


Auger Nr.	OEM Nr.	Description	Model	Picture
51891	-	Rep. Kit for Cabin ø20xø60x48	F 95	
51892	-	Rep. Kit for Cabin ø25	F 95 95 XF 95 XF 530 XF 95 XF 105	
51893	-	Rep. Kit for Cabin ø20xø60x48	F 95	
51894	-	Rep. Kit for Cabin ø20xø90x70	F 95 95 XF 95 XF 530 XF 95	
51895	-	Rep. Kit for Cabin ø25	F 95 95 XF 95 XF 530 XF 95	
51896	-	Rep. Kit for Cabin ø20xø90x70	95 XF 95 XF 530 F 95 XF 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
53429	1403 397 S	Rep. Kit for Cabin ø29xø70x117	LF 45 LF 55	 <p>53382 53389</p>
53430	1403 397 S1	Rep. Kit for Cabin ø29xø70x117	LF 45 LF 55	 <p>53382 53389</p>
53431	1403 089 S	Rep. Kit for Cabin ø11xø41.5x38	LF 45 LF 55	 <p>53390</p>
53450	-	Rep. Kit for Cabin ø20xø90x70	XF 95	 <p>53073 51884 53422 53409</p>
53451	-	Rep. Kit for Cabin ø25	XF 95	 <p>53409 53073 53422</p>
55212	1314 545 S	Rep. Kit for Cabin ø20xø90x70	XF 105 XF 95	 <p>51884 55189</p>







Auger Nr.	OEM Nr.	Description	Model		Picture
20116	1622 211	Cabin Shock Absorber, With Air Bellow	XF 105	CF 75 IV	
	1353 453		XF 95	CF 85	
	1353 450	75 CF	CF 85 IV		
	1321 590	ø25xø41.5	85 CF	LF 55	
	1285 393		CF 65		
	1265 281		CF 65 II		
	0375 224		CF 65 IV		
	1444 147		CF 75		
20117	1623 477	Cabin Shock Absorber, With Air Bellow	XF 105	CF 85	
	1321 591		XF 95	CF 85 IV	
	1371 066	65 CF	LF 55		
	1353 451	ø14xø41.5	75 CF		
	1353 454		85 CF		
	1285 394		CF 65		
	1265 282		CF 75		
	0299 862		CF 75 IV		
20072	1260 941	Shock Absorber For Cabin	F 65	CF 85	
	1265 271		F 75	CF 85 IV	
	1377 825	268 / 340	F 85	65 CF	
			CF 65	75 CF	
			CF 65 II	85 CF	
			CF 65 IV		
			CF 75		
			CF 75 IV		
20073	1265 276	Shock Absorber For Cabin	F 95		
	3755 221				
	0762 784	268 / 340			
20074	1377 828	Shock Absorber For Cabin	75 CF	F 65	
	1260 942		85 CF	F 75	
	1265 272	245 / 285	CF 65	F 85	
			CF 75	6,8,11 LT- ENGINES	
			CF 75 IV		
			CF 85		
			CF 85 IV		
65 CF					
20075	1265 277	Shock Absorber For Cabin	F 95		
	1265 275				
		238 / 281			

Auger Nr.	OEM Nr.	Description	Model	Picture
20076	1436 055 1303 516	Shock Absorber For Cabin 235 / 255	95 XF 95 XF 530 F 95 XF 95 FX 105	
20077	1319 672 1337 159 1387 327 1623 464	Shock Absorber For Cabin 278 / 340	95 XF 95 XF 530 F 95 XF 95 FX 105	
20078	1387 326 1623 465 1319 673	Shock Absorber For Cabin 238 / 283	95 XF 95 XF 530 F 95 XF 95 FX 105	
53387	1436 209	Cabin Bracket, Left ø30x128	65 CF 75 CF 85 CF CF 65 CF 65 II CF 75 CF 85 CF 85 IV	
53991	1436 210	Cabin Bracket, Right ø30x128	65 CF 75 CF 85 CF CF 65 CF 65 II CF 75 CF 85 CF 85 IV	

Auger Nr.	OEM Nr.	Description	Model	Picture
51842	0268 043	Stabilizer Bushing ø25.5xø35.5x23	F 65 F 75 F 85	
51843	0274 651	Stabilizer Bushing ø50xø60x23.5	75 CF 85 CF 95 XF 95 XF 530 F 5 - F 27 F 75 F 85 F 95	
51844	0274 650	Stabilizer Bushing ø40.5xø50x23.5	BUS 65 CF 75 CF 85 CF 95 XF 95 XF 530 F 5 - F 27 F 65	F 75 F 85 F 95 
51845	0371 465	Stabilizer Bushing ø25.5xø46x25	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27	
51846	0377 171	Stabilizer Bushing ø30xø55x27	F 28 - F 36 N 28 TT 2100 F 5 - F 27	
51847	0281 008	Stabilizer Bushing ø26.5xø41x69.5	6-8-11 ltr Engines BUS	

Auger Nr.	OEM Nr.	Description	Model	Picture	
51854	0299 108	Stabilizer Bushing	6-8-11 ltr Engines		
	0259 526	ø25.5xø45.5x49	BUS F 5 - F 27 F 95 F 28 - F 36 N 28 TT 2100		
51855	0299 106	Stabilizer Bushing	65CF	F 28 - F 36	
	0259 524	ø30.5xø56x57	BUS	N 28	
	0290 825		75 CF	TT 2100	
51832	0268 045	Stabilizer Plastic Bearing	85 CF	F 5 - F 27	
			95 XF	F 65	
			95 XF 530	F 75	
			CF 65	F 85	
			CF 75	F 95	
			CF 75 IV	XF 105	
			CF 85	XF 95	
			CF 85 IV		
			F 28 - F 36		
51833	0268 044	Stabilizer Plastic Bearing	65 CF	F 75	
			75 CF	F 85	
			85 CF	F 95	
			95 XF		
			CF 85		
			CF 85 IV		
			F 5 - F 27		
F 65					
51834	0291 280	Stabilizer Plastic Bearing	F 5 - F 27		
			ø37xø57.5x66		
51835	0538 329	Stabilizer Plastic Bearing	65 CF		
			75 CF		
			85 CF		
			F 5 - F 27		
			F 65		
			F 75		
			F 85		
F 95					

Auger Nr.	OEM Nr.	Description	Model	Picture	
51836	0278 040	Stabilizer Plastic Bearing ø38.5xø72.5x52	F 5 - F 27		
51837	0293 417	Stabilizer Plastic Bearing ø40xø70x37	F 28 - F 36 N 28 TT 2100 F 5 - F 27		
51838	0096 109	Stabilizer Plastic Bearing ø45xø76x60	75 CF 85 CF 95 XF 95 XF 530 F 5 - F 27 F 75 F 85 F 95		
51839	0763 523	Stabilizer Plastic Bearing ø51xø74.5x60	75 CF 85 CF 95 XF CF 75 CF 75 IV CF 85 CF 85 IV F 5 - F 27	F 75 F 85 F 95 XF 105 XF 95	
51852	0299 109 0259 525	Stabilizer Plastic Bearing ø40.5x63.5	Bus F 28 - F 36 N 28 TT 2100 F5 - F 27		
51853	0299 110 0259 523	Stabilizer Plastic Bearing ø51x76	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 65 CF 85 CF CF 65 CF 85		

Auger Nr.	OEM Nr.	Description	Model	Picture	
51867	-	Stabilizer Bearing Kit	65 CF F 5 - F 27 F 65 F 75 F 85 F 95		
51876	-	Stabilizer Bearing Kit	65 CF 75 CF 85 CF 95 XF CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 65 F 75 F 85 F 95 XF 95	
51877	-	Stabilizer Bearing Kit	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV	F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
51878	-	Stabilizer Bearing Kit ø20.5xø55x55	75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95		
51879	-	Stabilizer Bearing Kit	65 CF 75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95		
51880	0274 651 S1	Stabilizer Bearing Kit ø50xø60x23.5	75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95		

Auger Nr.	OEM Nr.	Description	Model	Picture	
53426	1283 618 S1	Stabilizer Bearing Kit	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV F 75	F 85 F 95 LF 55 XF 105 XF 95	
53427	1283 618 S2	Stabilizer Bearing Kit ø20xø60x59.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 75 F 85 F 95 LF 55 XF 105 XF 95 YTZ 95	
53428	1273 279 S	Stabilizer Bearing Kit ø16xø46.5x50	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 65 F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
53433	1400 396 S	Stabilizer Bearing Kit ø16xø36.5x48	LF 45 LF 55		
52706	1400 397	Washer ø16.5xø43.5x4	LF 45 LF 55		
51861	0082 522	Silent Block for Stabilizer ø55xø17/100	BUS YTZ 95		

Auger Nr.	OEM Nr.	Description	Model	Picture	
51848	0366 351	Stabilizer Mounting ø64xø84.5x60	75 CF	F 5 - F 27	
			85 CF	F 75	
			95 XF	F 85	
			95 XF 530	F 95	
			CF 75	LF 55	
			CF 75 IV	XF 105	
			CF 85	XF 95	
			CF 85 IV		
51849	0558 864	Stabilizer Mounting ø60xø86x60	65 CF	CF 85 IV	
			75 CF	F 5 - F 27	
			85 CF	F 65	
			95 XF	F 75	
			95 XF 530	F 85	
			CF 65	F 95	
			CF 75	XF 105	
			CF 75 IV	XF 95	
CF 85					
51856	1291 233	Stabilizer Mounting ø43xø61x60	75 CF	F 75	
			85 CF	F 85	
			95 XF	F 95	
			95 XF 530	XF 105	
			CF 75	XF 95	
			CF 75 IV	YTZ 95	
			CF 85		
			CF 85 IV		
51857	1288 000	Stabilizer Mounting ø38.5xø61x60	65 CF	CF 85 IV	
			75 CF	F 5 - F 27	
			85 CF	F 65	
			95 XF	F 75	
			CF 65	F 85	
			CF 75	F 95	
			CF 75 IV	XF 95	
			CF 85		
55201	1323 838	Stabilizer Mounting ø48xø83x75	65 CF	CF 85 IV	
			75 CF	F 28 - F 36 / N 28	
			85 CF	TT 2100	
			95 XF	F 65	
			95 XF 530	F 75	
			CF 65	F 85	
			CF 75	F95	
			CF 75 IV	XF 105	
CF 85	XF 95				
55202	1323839	Stabilizer Mounting ø55xø83x75	65 CF	TT 2100	
			75 CF	F 65	
			85 CF	F 75	
			95 XF	F 85	
			CF 75	F95	
			CF 75 IV	XF 105	
			CF 85	XF 95	
			CF 85 IV		
F 28 - F 36 / N 28					







Auger Nr.	OEM Nr.	Description	Model	Picture
53372	1402 572	Stabilizer Mounting ø40x40	LF 45	
53373	1402 590	Stabilizer Mounting ø48x54	F 55 LF 55	
53378	1402 587	Stabilizer Mounting ø46x54	LF 55	
51858	0010 761	Stabilizer Bearing ø39.5x66	BUS 65 CF 6-8-11 ltr Engines F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53368	1400 147	Stabilizer Bearing ø34x57.5	LF 55	
53369	1402 562	Stabilizer Bearing ø27.5x52.5	LF 45	

Auger Nr.	OEM Nr.	Description	Model	Picture	
51859	0295 726	Stabilizer Rubber Bushing ø20.5xø55x55	BUS 65 CF 75 CF 85 CF 95 XF 95 XF 530 F 5 - F 27 F 65 F 75 F 85 F 95		
51860	1283 618	Stabilizer Rubber Bushing ø20xø60x59.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85 CF 85 IV F 5 - F 27 F 65 F 75 F 85	F 95 LF 55 XF 105 XF 95 YTZ 95	
51863	0293 898	Stabilizer Rubber Bushing ø20.5xø55x56	BUS F 5 - F 27		
51907	1287 999 1273 279	Stabilizer Rubber Bushing ø16xø46.5x50	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85 CF 85 IV F 65	F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
53388	1400 396 ACHF431	Stabilizer Rubber Bushing ø16xø36.5x48	LF 45 LF 55		

Auger Nr.	OEM Nr.	Description	Model	Picture
53397	ACHB081	Stabilizer Rubber Bushing ø35.5xø61.5x51	F 55	
51851	0298 498	Stabilizer Half Bushing ø60xø95x80	BUS 75 CF 85 CF F 5 - F 27 F 75 F 85 F 95	
53202	0298 497	Stabilizer Half Bushing ø50xø95x80	BUS F 5 - F 27	
51911	0619 531	Stabilizer Bolt ø25x88	BUS F 28 - F 36 N28 TT 2100 F 5 - F 27	
51912	0619 565	Stabilizer Bolt ø30x99	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27	


Auger Nr.	OEM Nr.	Description	Model	Picture
53398	1340 297	Brake Shoe Spring ø39.5x160	65 CF 75 CF 85 CF 95 XF 95 XF530 CF 65 CF 75 CF 85 XF 95	
53399	0191 530	Brake Shoe Spring ø19x195	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53400	1279 502 0194 592	Brake Shoe Spring ø28x227	65 CF 6-8-11 Ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53401	0672 797	Brake Shoe Spring ø28.5x240	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 95	
53994	0198 025	Brake Shoe Pin ø19x66	BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F95	
53406	0075 566 0292 079	Brake Shoe Spring Pin ø13x56	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
53434	0681 090	Rep. Kit for Brake Shoe	75 CF 85 CF BUS CF 75 F 5 - F 27 F 95	
53435	-	Rep. Kit for Brake Shoe ø32	75 CF 85 CF BUS CF 75 F 5 - F 27 F 95	
53436	-	Rep. Kit for Brake Shoe	75 CF 85 CF BUS CF 75 F 5 - F 27 F 95	
53437	-	Rep. Kit for Brake Shoe	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53438	-	Rep. Kit for Brake Shoe ø31.7	65 CF 6-8-11 ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53439	-	Rep. Kit for Brake Shoe	BUS F 5 - F 27 F95	

Auger Nr.	OEM Nr.	Description	Model	Picture
53440	-	Rep. Kit for Brake Shoe	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53441	-	Rep. Kit for Brake Shoe	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53442	-	Rep. Kit for Brake Shoe	75 CF 85 CF F 5 - F 27 F 95 Bus CF 75	
55215	1602 395	Rep. Kit. for Camshaft	85 CF 95 XF CF 85 CF 85 IV XF 105 XF 95	
53402	0667 965	Brake Shoe Roller ø22xø42x28	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 85 XF 95 XF 105	
53403	0364 577	Brake Shoe Roller ø19xø42x24.5	65 CF F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95 BUS 6-8-11 ltr Engines	

Auger Nr.	OEM Nr.	Description	Model	Picture
51908	0145 450	Brake Shoe Pin ø31.7x95	65 CF 6-8-11 ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53404	1206 635 0067 481	Brake Shoe Pin ø19x51.5	65 CF 6-8-11 ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	
53405	0070 404 0371 807	Brake Shoe Pin ø22x56	75CF 85CF BUS CF75 F5 - F27 F 75 F 85 F 95	
53407	0096 242 0290 377	Brake Shoe Pin ø32x100.5	75CF 85CF BUS CF75 F5 - F27 F 75 F 85 F 95	
53391	0593 595 0290 378	Brake Shoe Bushing ø32xø36x20	75 CF 85 CF BUS CF 75 F 5 - F 27 F 95	
53392	0646 745 1333 402	Brake Camshaft Bushing ø42xø46x42	XF 95 65 CF 75 CF 85 CF 95 XF	
53408	0145 459	Brake Shoe Bushing ø32xø35x18.5	65 CF 6-8-11 ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
52146	-	Dust Cover ø34x25.5	85 CF 95 XF CF 85 CF 85 IV XF 105 XF 95	
52147	-	Dust Cover ø41x24.5	85 CF 95 XF CF 85 CF 85 IV XF 105 XF 95	
52148	-	Dust Cover ø41x20	85 CF 95 XF CF 85 CF 85 IV XF 105 XF 95	
53961	1694 354	Dust Cover ø36xø63x19	CF 75 IV CF 85 IV XF 105	
55218	1694 352	Brake Adjuster Rep. Kit ø55x112 L	CF 75 IV CF 85 IV XF 105	
55219	1694 353	Brake Adjuster Rep. Kit ø55x112 R	CF 75 IV CF 85 IV XF 105	

Auger Nr.	OEM Nr.	Description	Model	Picture
55221	1694 370	Brake Adjuster Rep. Kit $\varnothing 37 \times \varnothing 47.5 \times 5.5$	CF 75 IV CF 85 IV XF 105	
55220	1694 366	Brake Adjuster Rep. Kit	CF 75 IV CF 85 IV XF 105	
55222	1694 365	Brake Adjuster Rep. Kit	CF 75 IV CF 85 IV XF 105	
55223	1694367	Brake Adjuster Rep. Kit	CF 75 IV CF 85 IV XF 105	
55198	1694 342	Bushing for Brake Adjuster $\varnothing 38.4 \times \varnothing 43 \times 26$	CF 75 IV CF 85 IV XF 105	
55208	1694 355	Pin for Brake Adjuster $\varnothing 12.6 \times 59$	CF 75 IV CF 85 IV XF 105	

Diaphragms - Normal Stroke
Auger Nr.: 52576

O.E.M. Nr. 1257 928

Type 9"

Auger Nr.: 52578

O.E.M. Nr. 1325 347

Type 12"

Auger Nr.: 52580

O.E.M. Nr. FBU 9962 - 0721 187 - 1325 346

Type 16"

Auger Nr.: 52581

O.E.M. Nr. 0303 055 - FBU 8676 - 1325 345

Type 20"

Auger Nr.: 52582

O.E.M. Nr. 0706 123

Type 24"

Auger Nr.: 52583

O.E.M. Nr. 0305 049 - 0533 891 - FBU 8677

Type 30"

Auger Nr.: 52584

O.E.M. Nr. 0721 172

Type 36"


Diaphragms - Long Stroke
Auger Nr.: 52585

O.E.M. Nr. 0689 511 - FBU 9614

Type 16"

Auger Nr.: 52586

O.E.M. Nr. 0689 366

Type 20"

Auger Nr.: 52587

O.E.M. Nr. 0691 763

Type 24"


Auger Nr.: 52588






O.E.M. Nr. 0694 277

Type 30"









Auger Nr.	OEM Nr.	Description	Model	Picture
21004	-	Service Brake Chamber (for disc brake) 97.5/111.5xM16x1.5x164	T16 STR 57	
21005	1505 241	Service Brake Chamber (for disc brake) (with repair kit) 97.5/111.5xM16x1.5x164	T16 STR 57	
21006	-	Service Brake Chamber (for disc brake) 105xM16x1.5x174	T20 STR 64	
21007	1517 954	Service Brake Chamber (for disc brake) (with repair kit) 105/121xM16x1.5x174	T20 STR 64	
21008	-	Service Brake Chamber (for disc brake) 103xM16x1.5x186	T24 STR 64	
21009	1517 956	Service Brake Chamber (for disc brake) (with repair kit) 103/117.5xM16x1.5x186	T24 STR 64	



Auger Nr.	OEM Nr.	Description	Model	Picture
21010	-	Service Brake Chamber (for drum brake) 112.5/126xM16x1.5x164	T16 STR 75	
21011	0834 481 0745 398	Service Brake Chamber (for drum brake) (with repair kit) 112.5/353xM16x1.5x164	T16 STR 75	
21012	-	Service Brake Chamber (for drum brake) 113/126xM16x1.5x174	T20 STR 75	
21013	0834 482	Service Brake Chamber (for drum brake) (with repair kit) 113/353xM16x1.5x174	T20 STR 75	
21014	-	Service Brake Chamber (for drum brake) 112.5/126xM16x1.5x186	T24 STR 75	
21015	0834 483	Service Brake Chamber (for drum brake) (with repair kit) 112.5/353xM16x1.5x186	T24 STR 75	

Auger Nr.	OEM Nr.	Description	Model	Picture
21016	-	Service Brake Chamber (for drum brake) 117.5/131xM16x1.5x208	T30 STR 75	
21017	0834 484 0705 707	Service Brake Chamber (for drum brake) (with repair kit) 117.5/358xM16x1.5x208	T30 STR 75	
21018	-	Double Diaphragm Brake Chamber (for drum brake) 274.5/560.5xM16x1.5x208	T24-30 STR 75/75	
21019	1325 352	Double Diaphragm Brake Chamber (for drum brake) (with repair kit) 274.5/602.5xM16x1.5x208	T24-30 STR 75/75	
21020	-	Double Diaphragm Brake Chamber (for drum brake) 271.5/557.5xM16x1.5x208	T30-30 STR 75/75	
21021	1325 351	Double Diaphragm Brake Chamber (for drum brake) (with repair kit) 271.5/599.5xM16x1.5x208	T30-30 STR 75/75	

Auger Nr.	OEM Nr.	Description	Model		Picture
31010	1238372 1G35170/0040	Brake Disc 170x460xM16X2	SB, SBR, SB2000/3000, SBR3000 SB, SBR, SB2000/3000, SBR3000		
31011	1296573/01	Brake Disc 200x432xM16X2	Leyland		
31012	AMPB 860	Brake Disc 155x375xM14X1,5	DAF FA55.150 - FA55.230		
55073	1693 978 1393 561 1690 788	Lock Screw With Plate 21x64.5xM8x1.25/40	65 CF 75 CF 85 CF CF 65 CF 65II CF 65IV CF 75 CF 75IV	CF 85 CF 85IV LF55 LF55IV XF 95 XF 105	
55183	1691 889 1393 560	Lock Plate 19x34.5x18.5	65 CF 75 CF 85 CF CF 65 CF 65II CF 65IV CF 75 CF 75IV	CF 85 CF 85IV LF55 LF55IV XF 95 XF 105	

Auger Nr.	OEM Nr.	Description	Model	Picture
54560	AMPA141	Rep. Kit for Brake Caliper Wabco Type	-	
54561	1519363	Rep. Kit for Brake Caliper Wabco Type	-	
54562	1440505	Rep. Kit for Brake Caliper Wabco Type	-	
54563	1518458	Rep. Kit for Brake Caliper Wabco Type	-	
54564	1505880	Rep. Kit for Brake Caliper Wabco Type	-	
54565	1517407	Rep. Kit for Brake Caliper Wabco Type	-	

Auger Nr.	OEM Nr.	Description	Model	Picture
54566	1436853	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55335 55326 55325 55354</p>
54567	1517794	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55341</p>
54568	AMPA137	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55328 55338</p>
54569	0865966	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55334 55299 55379 55322</p>
54570	FBU1298	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55358</p>
54528	1517354	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55353 55332 55314 55313</p>

Auger Nr.	OEM Nr.	Description	Model	Picture
54558	0865965	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55350 55334 55379 55299 55322</p>
54559	1505890	Rep. Kit for Brake Caliper Wabco Type	-	 <p>55299 55323 55334 55337 55354</p>




Auger Nr.	O.E.M. Nr.	Dia.	Capacity	Description
21952	1402330 - ABRA621	ø206	10 L	CF 65, CF 75, CF 75 IV
21953	1402340 - ABRA034	ø206	20 L	CF85, LF45
21954	1701700 - ABRA557	ø206	20 L	LF45
21955	1402294 - ABRA361	ø246	20 L	LF55
21956	1402284 - ABRA383	ø276	30 L	LF55, LF45
21902	1505414	ø206	20 L	F 45, F 55
21903	1505415	ø246	20 L	-
21904	1506425	ø246	30 L	-
21905	1506426	ø276	40 L	-
21906	1505417	ø276	60 L	-
21910	1506423	ø396	80 L	-




Auger Nr.	O.E.M. Nr.	A	B	C	Type	Repair Kit
54480	0657 061	ø50	ø58	25	1	55217 - 52571
55253	1369 877	ø55	ø63	20	1	55216
55254	0275 834	ø55	ø63	29	1	55216
55255	1296 486	ø50	ø58	20	1	55217
54810	0657 051	ø31,5	ø50	60,3	2	52571
55251	1369 876	ø40.5	ø55	47.5	2	55216
55252	1367 323	ø31.5	ø50	47.5	2	55217
54854	0657 062	ø50,5	ø58	4	3	52571
54855	0376 039	ø59,5	ø82	8,5	3	55217 - 52571
55256	1365 949	ø54	ø63	6	3	55216
55257	0378 153	ø69.5	ø92	8	3	55216
55258	1352 849	ø49	ø58	6	3	55217

Auger Nr.	OEM Nr.	Description	Model	Picture
52571	0681 706	King Pin Set	65 CF	
		M27x3/ø31.5/ø41.8x271	75 CF	
55216	0683 470	King Pin Set	85 CF	
		M33x3.5/ø40.5/ø55x266	CF 75 IV	
55217	0683 499	King Pin Set	CF 75	
		M27x3/ø31.5/50x253	CF 85	
53168	0371 698	Cap	CF 85 IV	
		SW34/39.5	CF 65	


Type-1




Type-2




Type-3



Type-4



Type-5







Auger Nr.	O.E.M. Nr.	A	B	C	D	Type
52876	1321 936	ø67	43	ø19	130	1
54577	1243 618	ø67	43	ø17	115	1
51443	0067 354	ø75	48	ø19	130	1
51445	0689 748	ø75	48	ø17	115	1
51972	1252 284	ø75	48	ø21	130	1
53423	1376 728	ø75	52	ø21	130	1
53424	1376 729	ø75	52	ø23	152	1
51134	0691 703	ø85	54	ø21	152	1
51137	0689 749	ø85	54	ø19	130	1
51444	0691 709 - 0513 757	ø85	54	ø21	130	1
53443	0698 724	ø85	54	ø23	152	1
51619	0696 321 - 1208 071	ø95	61	ø23	152	1
54626	0689 747	ø85	54	M39x1.5	171	2
54576	1252 283	ø67	43	-	-	3
51447	1271 124	ø72	ø19	130	-	4
51142	0693 778	ø80	ø21	152	-	4
53201	1398 368	ø72	M20x1.5	46	-	5
51451	0691 704	ø72	M20x1.5	46	-	5
52953	0069 600	ø72	M20x1.5	46	-	5
52952	1376 730	ø72	M20x1.5	46	-	5
51450	0696 320	ø90	M24x1.5	59	-	5
55211	1208 070	ø90	M24x1.5	59	-	5






Auger Nr.	OEM Nr.	Description	Model	Picture	
51134	0691 703	Rep. Kit for Axle Rod ø85xø21/152	F 28 - F 36 N 28 TT 2100 F 5 - F 27		
51137	0689 749	Rep. Kit for Axle Rod ø85xø19/130	BUS		
51443	0067 354	Rep. Kit for Axle Rod ø75xø19/130	BUS		
51444	0691 709 0513 757	Rep. Kit for Axle Rod ø85xø21/130	65 CF 75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 75 IV CF 85 CF 85 IV	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 65 F 75 F 85 F 95 XF 105 XF 95	
51445	0689 748	Rep. Kit for Axle Rod ø75xø17/115	75 CF 85 CF 95 XF BUS CF 75 CF 75 IV CF 85 CF 85 IV	F 75 F 85 F 95 XF 105 XF 95	
51619	0696 321 1208 071	Rep. Kit for Axle Rod ø95xø23/152	75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 75 IV CF 85 CF 85 IV F 28 - F 36	N 28 TT 2100 F 5 - F 27 F75 F85 F95 XF 105 XF 95 YTZ 95	

Auger Nr.	OEM Nr.	Description	Model	Picture	
51972	1252 284	Rep. Kit for Axle Rod ø75xø21/130	BUS		
52876	1321 936	Rep. Kit for Axle Rod ø67xø19/130	75 CF 85 CF CF 75 CF 75 IV CF 85 CF 85 IV F 75 F 85		
53423	1376 728	Rep. Kit for Axle Rod ø75xø21/130	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 5 - F 27 F 65 F 75 F 85 F 95 LF 55 XF 105 XF 95	
53424	1376 729	Rep. Kit for Axle Rod ø75xø23/152	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 75 CF 75 IV CF 85	CF 85 IV F 5 - F 27 F 65 F 75 F 85 F 95 LF 55 XF 105 XF 95	
53443	0698 724	Rep. Kit for Axle Rod ø85xø23/152	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV	CF 85 CF 85 IV F 5 - F 27 F 65 F 75 F 85 F 95	
54576	1252 283	Rep. Kit for Axle Rod ø67/ø17	BUS		
54577	1243 618	Rep. Kit for Axle Rod ø67xø17/115	85 CF 95 XF CF 75 CF 75 IV CF 85 CF 85 IV F 28 - F 36 N 28 TT 2100		

Auger Nr.	OEM Nr.	Description	Model	Picture	
54626	0689 747	Rep. Kit for Axle Rod ø85xM39x1.5/171	F 28 F 36 N 28 TT 2100		
51133	1445 656	Rep. Kit for Axle Rod ø108xM24x1.5/68	65 CF 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85	CF 85 IV LF 55 XF 105 XF 95	
55055	1676 776	Rep. Kit for Axle Rod ø108xM24x1.5/68	65 CF 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85	CF 85 IV LF 55 XF 105 XF 95	
54351	1408 543	Axle Rod Mountung ø21/135xø90.5/170	LF 55		
53371	1401 137	Axle Rod Mountung ø90.5x73	LF 55		
55211	1208 070	Rep. Kit for Axle Rod M24x1.5/ø90x59	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV	F 28 - F 36 / N 28 TT 2100 F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
51142	0693 778	Rep. Kit for Axle Rod ø80xø21/152	95 XF CF 85 CF 85 IV F 28 - F 36 N 28 TT 2100 F 95 XF 105 XF 95		

Auger Nr.	OEM Nr.	Description	Model	Picture	
51447	1271 124	Rep. Kit for Axle Rod ø72xø19/130	95 XF CF 85 CF 85 IV F 95 XF 105 XF 95		
51450	0696 320	Rep. Kit for Axle Rod M24x1.5/ø90	75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV F 28 - F 36 N 28	TT 2100 F 5 - F 27 F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
51451	0691 704	Rep. Kit for Axle Rod M20x1.5/ø72	F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 95		
52952	1376 730	Rep. Kit for Axle Rod M20x1.5/ø72	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 85 F 5 - F 27 F 65	F 75 F 85 F 95	
52953	0069 600	Rep. Kit for Axle Rod M20x1.5/ø72	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 85 F 5 - F 27 F 65	F 75 F 85 F 95	
53201	1398 368	Rep. Kit for Axle Rod M20x1.5/ø72	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 85 F 75 F 85 F 95		

Auger Nr.	OEM Nr.	Description	Model	Picture
15080	0649 819	V-Arm	75 CF	
	1620 437	L: 602	85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV F 28 - F 36 / N 28 TT 2100 F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
15081	1617 096	V-Arm	65 CF	
	1368 270	L: 609	75 CF	
	1390 932		85 CF	
	1361 651		95 XF	
	0080 521		95 XF 530	
	0276 875		CF 85 F 28 - F 36 / N 28 TT 2100 F 65 F 75 F 85 F 95	
10060	1228 605	Tie rod steering	F 95	
		L: 990		
10081	1602 821	Tie rod steering	65 CF	
		L: 865	75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85 CF 85 IV	

Auger Nr.	OEM Nr.	Description	Model	Picture	
10119	1286 343	Tie rod steering	75 CF	XF 105	
	1353 396	L: 1700	85 CF XF 95 CF 75 CF 75 N CF 85 CF 85 IV F 75 F 85 F 95	XF 95	
10122	1270 853	Tie rod steering	65 CF	F 65	
	1353 391 1359 391	L: 1700	75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 65 II CF 65 IV F 75 F 75 IV CF 85 CF 85 N	F 75 F 85 F 95 XF 105 XF 95	
10125	1286 341	Tie rod steering	75 CF		
	0275 961	L: 1130	85 CF 95 XF 95 XF 95 XF 530 F 75 F 85 F 95		
10126	1286 342	Tie rod steering	75 CF		
	0275 962	L: 1686	85 CF 95 XF 95 XF 530 F 75 F 85 F 95		
10130	0288 280	Tie rod steering	F 65		
		L: 1700	F 75 F 85 F 95		

Auger Nr.	OEM Nr.	Description	Model	Picture
10669	1361 157	Tie rod steering L: 1620	-	
10670	1143 322	Tie rod steering L: 790	-	 10003 10003
10114	0094 038 0525 433 0554 765	Drag Link L: 995	F 95	 10001 10001
10115	1351 734 1385 499 1291 060	Drag Link L: 1005	95 XF 95 XF 530 F 95 XF 95	 10003 10003
10116	0094 613 0362 413	Drag Link L: 1008	F 95	 10001 10001

Auger Nr.	OEM Nr.	Description	Model	Picture
10117	1283 211 1385 497 1351 714	Drag Link L: 876	65 CF 75 CF 85 CF F 65 F 75 F 85	 <div style="display: flex; justify-content: space-around;"> 10003 10003 </div>
10118	1385 492 1283 212 1351 715 1247 957	Drag Link L: 848	65 CF 75 CF 85 CF F 65 F 75 F 85	 <div style="display: flex; justify-content: space-around;"> 10003 10003 </div>
10120	1257 991 1351 718 1385 493	Drag Link L: 860	75 CF 85 CF F 75 F 85	 <div style="display: flex; justify-content: space-around;"> 10003 10003 </div>
10121	1257 992 1351 732 1385 490	Drag Link L: 831	75 CF 85 CF F 85	 <div style="display: flex; justify-content: space-around;"> 10009 10009 </div>
10123	1291 048 1351 735 1385 500	Drag Link L: 1008	95 XF	 <div style="display: flex; justify-content: space-around;"> 10003 10003 </div>








Auger Nr.	OEM Nr.	Description	Model	Picture
10124	0094 044	Drag Link L: 1130	BUS	  10001  10001
10127	1240 647	Drag Link L: 1008	F 95	  10003  10003
10128	0094 029 0117 343	Drag Link L: 872	F 28 - F 36 N 28 TT 2100	  10012  10012
10129	0094 037	Drag Link L: 998	F 95	  10001  10001
10526	1283 203	Drag Link L:930	95 XF F 95	  10003  10003

Auger Nr.	OEM Nr.	Description	Model	Picture
10527	1247 956	Drag Link L: 820	65 CF 75 CF 85 CF F 65 F 75 F 85	 <p>10003 10003</p>
10539	1263 044 1351 725 1385 514	Drag Link L: 1675	75 CF 85 CF F 75 F 85	 <p>10602 10602</p>
10540	0890 992	Drag Link L: 658	F 28 - F 36 N 28 TT 2100	 <p>10001 10001</p>
10664	1143 324 1191 900	Drag Link L: 1150	-	 <p>10003 10003</p>
53393	1261 591	Ball Joint M6x1/310	65 CF F 5 - F 27 75 CF F 65 85 CF F 75 95 XF F 85 XF 530 F 95 CF 65 LF 55 CF 75 XF 105 CF 75 IV XF 95 CF 85 CF 85 IV	

Auger Nr.	OEM Nr.	Description	Model	Picture	
10001	0607 981	Tie Rod	65 CF	F 95	
	0698 450	L:125	75 CF	CF 75	
	1257 890	M 30x1,5 RHT	85 CF	CF 85	
	1603 789		95 XF	XF 105	
			95 XF 530	XF 95	
			F 28 - F 36	BUS	
			F 75		
			F 85		
10002	0607 053	Tie Rod	85 CF		
	0696 225	L: 125	BUS	F 5 - F 27	
	1228 115	M30x1.5 LHT	F 5 - F 27		
	0696 205		CF 65		
	1329 134		F 95		
10003	0586 753	Tie Rod	BUS		
	0607 999	L: 115	F 28 - F 36		
	0694 298	M30x1,5 RHT	TT 2100		
	0694 360		65 CF		
	0698 609		75 CF		
	1229 944		85 CF		
			F 65		
		F 75			
		F 85			
10004	0607 998	Tie Rod	BUS	CF 65 IV	
	1319 838	L: 115	F 28 - F 36	CF 75	
	1338 714	M30x1,5 LHT	N 28	CF 75 IV	
	1315 447		TT 2100	CF 85	
	311 300		65 CF	F 65	
			75 CF	F 75	
			85 CF	F 85	
			95 XF	F95	
			95 XF 530	LF 55 IV	
			CF 65	XF 105	
		CF 65 II	XF 95		
10005	0067 389	Tie Rod	75 CF		
		L: 133	85 CF		
		M48x1,5 RHT	F 65		
			F 75		
			F 85		
			F95		
10006	0067 303	Tie Rod	75 CF		
		L: 133	85 CF		
		M48x1,5 LHT	F 65		
			F 75		
			F 85		
			F95		

Auger Nr.	OEM Nr.	Description	Model	Picture
10007	0110 197	Tie Rod	6,8,11 LT - ENGINES	
	0607 451	L: 105	F 5 - F 27	
	0607 453	M28x1,5 RHT	CF 65	
	1228 114		CF 75	
	1373 135		CF 75 IV	
	ACU 9242		CF 85 CF 85 IV XF 105	
10008	0110 196	Tie Rod	F 5 - F 27	
	0607 452	L: 105	CF 65	
	1373 137	M28x1,5 LHT		
	ACU 9241			
10009	1320 855	Tie Rod	65 CF	
	1342 026	L: 141 M 30x1,5 RHT	75 CF 85 CF 95 XF CF 75 CF 85 F 5 - 27 F 65 F 75	
10010	ACU 9240	Tie Rod	45 FA	
		L: 175 M28x1,5 RHT		
10011	ACU 9239	Tie Rod	45 FA	
		L: 175 M28x1,5 LHT		
10012	0586 714	Tie Rod	BUS	
	0607 073	L: 135	F 28 - F 36	
	0609 634	M30x1,5 RHT	N 28	
	0609 643		TT 2100	
	0696 226			
	1228 110			
10013	-	Tie Rod	-	
		L: 135		

Auger Nr.	OEM Nr.	Description	Model	Picture
10014	1235 514	Tie Rod L: 133 M 52x1,5 RHT	75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95	
10015	1235 515	Tie Rod L: 133 M52x1,5 LHT	75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95	
10016	0606 923	Tie Rod L: 133 M46x1,5 RHT	BUS F 28 - F 36 N 28 TT 2100 F 95	
10017	0606 922	Tie Rod L: 133 M46x1,5 LHT	75 CF 85 CF 95 XF 95 XF 530 F 75 F 85 F 95	
10018	1488 890	Tie Rod L: 143 M30x1,5 RHT	95 XF 85 CF F 95	
10086	1330 981	Tie Rod L: 74.5 M10x1.5 LHT	95 XF F 95	
10601	1310 760	Tie Rod L: 141 M30x1,5 LHT	75 CF 85 CF 95 XF F 85	

Auger Nr.	OEM Nr.	Description	Model	Picture	
10602	1344 684	Tie Rod L: 115 M24x1,5 RHT	75 CF 85 CF 95 XF F 75 F 85		
10152	1330 987	Ball Joint	95 XF F 95		
10567	0386 930	Ball Joint L: 86 M14x1,5 RHT	BUS 6,8,11 LT - ENGINES LF 45 LF 55 XF 95 XF 105 65 CF 75 CF 85 CF	95 XF CF 75 CF 85 F 28 - F 36 N 28 TT 2100 F 65 F 75 F 85 F 95	
10574	1249 129 0656 085 0589 333	Ball Joint L: 56 M12x1,75 RHT	65 CF 75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 75 IV CF 85 CF 85IV F 28 - F 36	N 28 TT 2100 F 65 F 75 F 85 F 95 XF 105 XF 95 F 5 - F27 LF 55	
10575	1249 088 0592 106 0656 084	Ball Joint L: 56 M12x1,75 LHT	65 CF 75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 75 IV CF 85 CF 85IV F 28 - F 36	N 28 TT 2100 F 65 F 75 F 85 F 95 XF 105 XF 95 F 5 - F27 LF 55	
10588	1400 143	Ball Joint M16x1.5	LF 55		
10589	1401 845	Ball Joint M14x1.5	LF 45		







Auger Nr.	OEM Nr.	Description	Model	Picture
53367	1252 280	Engine Mounting 119x193x154	6-8-11 Ltr Engines F 75 F 85 F 95	
53995	0742 607	Engine Mounting 110x193x159	6-8-11 Ltr Engines 75 CF 85 CF 95 XF CF 75 CF 85 CF 85 IV F 95 XF 95	
53410	1212 816	Engine Mounting 191x300x160	6-8-11 Ltr Engines F 75 F 85 F 95	
53414	1212 817	Engine Mounting 191x300x165	6-8-11 Ltr Engines F 75 F 85 F 95	
53415	1292 419	Engine Mounting 191x300x170	6-8-11 Ltr Engines 75 CF 85 CF 95 XF CF 75 CF 85 CF 85 IV F 95 XF 95	
53927	1292 418	Engine Mounting 190x300x165	6-8-11 Ltr Engines 75 CF 85 CF 95 XF CF 75 CF 85 CF 85 IV F 95 XF 95	
53416	1664 140	Engine Mounting 110x162x142	6-8-11 Ltr Engines 75 CF 85 CF 95 XF CF 75 CF 85 CF 85IV F 95 XF 95 YTZ 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
55190	1740 904 1691 743	Propeller Shaft Bearing Ø55	CF 75 IV CF 85 IV XF 105	
55433	1435 557 1323 765 1288 220	Propeller Shaft Bearing ø65	65 CF 75 CF 85 CF 95 XF F 65 F 75	
55434	0102 204	Propeller Shaft Bearing ø60	F 28 - F 36 / N 28 / TT 2100 F 95 BUS	
55435	1235 569	Propeller Shaft Bearing ø70	85 CF 95 XF 95 XF 530 F 28 - F 36 / N 28 / TT 2100 F 85 F 95	
55436	0608 924	Propeller Shaft Bearing ø35	CF 65	
55437	0102 203	Propeller Shaft Bearing ø55	F 28 - F 36 / N 28 / TT 2100 BUS	
55438	1288 242	Propeller Shaft Bearing ø70	CF 75 IV CF 85 CF 85 IV F 95 XF 95 XF 105	







Auger Nr.	OEM Nr.	Description	Model	Picture	
55439	1425 157 1288 231 1364 376	Propeller Shaft Bearing ø75	85 CF 95 XF 95 XF 530 CF 75 CF 85 F 85 F 95 XF 95		
55440	1298 157 1252 249	Propeller Shaft Bearing ø55	65 CF 75 CF 85 CF 95 XF CF 75 F 28 - F 36 / N 28 / TT 2100 F 65 F 75 F 85 F 95		
53169	1284 698	Silent Block for Gearbox ø20xø38x34	F 95		
53170	1391 518	Rep. Kit for Gear Shift Lever ø21.5xø47x28	65 CF 6-8-11 Ltr Engines 75 CF 85 CF CF 65 CF 75 CF 75 IV CF 85 CF 85 IV LF 55		
51865	0221 342	Rubber Mounting for Radiator M12/ø60x39	6-8-11 ltr Engines 95 XF 95 XF 530 CF 65 CF 75 F 28 - F 36 N 28 TT 2100	F 5 - F 27 F 65 F 75 F 85 F 95 XF 105 XF 95 YTZ 95	
52501	0240 693	Rubber Mounting for Radiator M12/ø59.5x37	6-8-11 Ltr Engines BUS F 28 - F 36 N 28 TT 2100 F 5 - F 27 F 95		
53411	1294 247	Radiator Hose ø61xø73x435	6-8-11 Ltr Engines F 95 95 XF 530		

Auger Nr.	OEM Nr.	Description	Model	Picture
53412	1293 809	Radiator Hose ø61xø74x440	6-8-11 Ltr Engines 95 XF F 95 XF 95	
53413	1353 922	Radiator Hose ø60xø70x340	6-8-11 Ltr Engines 95 XF F 95 XF 95	
53417	1297 739	Radiator Hose ø60 mm	95 XF 530	
53418	1293 807	Radiator Hose ø27/ø32	6-8-11 Ltr Engines 95 XF F 95 XF 95	
53419	1293 808	Radiator Hose ø21/ø28	6-8-11 Ltr Engines 95 XF F 95 XF 95	
53420	1338 931	Radiator Hose ø60	95 XF 530	
53928	1290 141	Radiator Hose ø32/ø44	95 XF 530 F 95	

Auger Nr.	OEM Nr.	Description	Model	Picture
54962	0292 577	Silicone Hose	95 XF	
	0291 452	ø100x130	95 XF 530	
	1286 075		F 95	
	1346 328		XF 95	
54963	1378 391	Silicone Hose ø100x400	95 XF XF 95	
55010	1377 572	Silicone Hose	85 CF	
	0528 299	ø76x75	95 XF	
	0281 514		CF 85	
			CF 85 IV XF 95 YTZ 95	
55011	1204 236	Silicone Hose ø100x120	95 XF XF 95	
55022	1650 940	Silicone Hose ø50xø55x110	CF 75 CF 75 IV CF 85 CF 85 IV XF 105 XF 95 YTZ 95	
55036	1353 428 0084 027	Silicone Hose ø100x155/195	85 CF	
55045	1149 478	Silicone Hose ø50/ø60x30/120	-	

Auger Nr.	OEM Nr.	Description	Model	Picture	
52530	1238 280	Gas Spring 530 mm / 400N	95 XF 95 XF 530 F 95 XF 95		
52656	0758 296	Gas Spring 405 mm / 200 N	65 CF 75 CF 85 CF F 65 F 75 F 85		
55184	1651 601 1451 195	Gas Spring 475mm/400N	95 XF 95 XF 530 F 95 XF 105 XF 95 YTZ 95		
55185	1400 705	Gas Spring 615mm/215N	LF 45 LF 55		
55186	1296 632	Gas Spring 485mm/300N	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 65 CF 65 II CF 65 IV CF 75	CF 75 IV CF 85 CF 85 IV F 95 XF 105 XF 95 YTZ 95	
55187	1372 540	Gas Spring 670mm/240N	65 CF 75 CF 85 CF CF 65 CF 65 II CF 65 IV CF 75 CF 75 IV CF 85 CF 85 IV		

Auger Nr.	OEM Nr.	Description	Model	Picture	
55188	1323 677	Gas Spring 330mm	95 XF 95 XF 530 F 95 XF 105 XF 95 YTZ 95		
51730	0119 140	Rubber Bushing for Shock Absorber ø24.5xø48x25.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 85 CF 85IV F 28 - F 36	N 28 TT 2100 F 5 - F 27 F 65 F 75 F 85 F 95 XF 95	
51919	0698 429	Rubber Bushing for Shock Absorber ø24.5xø40x39.5	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 75 IV CF 85 CF 85 IV F 28 - F 36 N 28 TT 2100	F 5 - F 27 F 65 F 75 F 85 F 95 XF 105 XF 95	
51920	0699 425	Rubber Bushing for Shock Absorber ø34.5xø57x42	65 CF 75 CF 85 CF 95 XF 95 XF 530 CF 75 CF 85 CF 85 IV F 5 - F 27	F 65 F 75 F 85 F 95 XF 105 XF 95	
51922	0109 860	Rubber Bushing for Shock Absorber ø20.5xø59.5x31.5	75 CF 85 CF 95 XF 95 XF 530 BUS CF 75 CF 85 CF 85 IV F 28 - F 36	N 28 TT 2100 F 5 - F 27 F 75 F 85 F 95 XF 95	
53494	1620 344	Rubber Bushing for Shock Absorber ø19xø49.5x20	LF 45 LF 55		

Auger Nr.	OEM Nr.	Description	Model	Picture		
20013	0388165 S 0388167 S	Piston For Air Bellow	65 CF	CF 75 IV		
		ø230x135	75 CF	CF 85		
		85 CF	CF 85 IV			
		95 XF	F 28 - F36			
		95 XF 530	N 28			
		BUS	TT 2100			
		CF 65	LF 55			
		CF 75	XF 105			
52859	0285 530	Rubber Mounting for Air Suspension	75 CF	F 2500	SB 230	
			85 CF	F 2700	SB 2300	
			95 XF	F 2800	SB 2700	
			95 XF 530	F 2900	SB 2750	
		M8xø41x30	CF 85	F 3200	SB 3000	
			CF 85 II	F 3300	SB 4000	
			CF 85 IV	F 3600	SBG 220	
			F 1100	F 75	SBR 230	
			F 1300	F 85	SBR 3000	
			F 1600	F 95	SBR 3015	
			F 1700	SB 200	SBR 4000	
			F 1800	SB 210	XF 105	
			F 1900	SB 2100	XF 95	
			F 2100	SB 220	YTZ 95	
			F 2300	SB 225		
51864	1233 247	Air Filter Mounting	65 CF	F 65/75/85/95		
			75 CF	XF 105		
		M8/M10xSW30x31	85 CF	XF 95		
			6-8-11 ltr Engines	YT Z95		
			95 XF			
			XF 530			
51866	0088 371	Air Filter Mounting	6-8-11 ltr Engines			
			95 XF			
		M8/M10xSW31x30	95 XF 530			
			F 28 - F 36			
			N 28			
			TT 2100			
			F5 - F27			
	F 95					
52861	1371 806	Air Filter Mounting	65 CF			
			6-8-11 Ltr Engines			
			F 75/85			
		M8xSW30x43	CF 65/65 II/65 IV			
			CF 75/75 IV			
			CF 85			
			CF 85 IV			
			F 75			
	LF 45/ 55					
53945	0740 396	Bellows	65 CF			
			6-8-11 Ltr Engines			
			75 CF			
			85 CF			
		116x322x225	F 28 - F 36			
			N 28			
			TT 2100			
			F 5 - F 27			
			F 65			
			F 75			
			F 85			
	F 95					

